



# 4430 Tractor



## TECHNICAL MANUAL

4430  
Tractor

TM1057 (01NOV88) English



**TM1057 (01NOV88)**

LITHO IN U.S.A. (REVISED)  
ENGLISH





**4430 TRACTOR**  
**Serial No. (        -33109)**  
**TECHNICAL MANUAL**  
**TM-1057 (SEP-77)**


**CONTENTS**

<b>SECTION 10—GENERAL</b>	<b>SECTION 50—POWER TRAIN</b>
Group 5—General Tractor Specifications	Group 5—Perma-Clutch
Group 10—Predelivery, Delivery, and After-Sale Services	Group 10—Creeper Transmission
Group 15—Tune-Up	Group 15—Syncro-Range Transmission
Group 20—Lubrication	Group 20—Quad-Range Transmission
Group 25—Separation	Group 25—Power Shift Transmission
Group 30—Specifications and Special Tools	Group 30—Differential
	Group 35—Final Drive
	Group 40—Hi-Crop Final Drive
	Group 45—PTO, Perma-Clutch
<b>SECTION 20—ENGINE</b>	Group 50—PTO, Power Shift
Group 5—General Information and Diagnosis	Group 55—Power Front-Wheel Drive
Group 10—Cylinder Head, Valve Train, and Camshaft	Group 60—Specifications and Special Tools
Group 15—Cylinder Block, Liners, Pistons, and Rods	<b>SECTION 60—STEERING AND BRAKES</b>
Group 20—Crankshaft, Main Bearings, and Flywheel	Group 5—General Information
Group 25—Lubricating System	<b>SECTION 70—HYDRAULIC SYSTEM</b>
Group 30—Cooling System	Group 5—General Information
Group 35—Specifications and Special Tools	Group 6—General Hydraulic System Diagnosis and Tests
	Group 10—Main Reservoir, Filters, Valves, and Oil Cooler
<b>SECTION 30—FUEL SYSTEM</b>	Group 15—Hydraulic Pumps
Group 5—Diagnosing Malfunctions	Group 20—Early Model Power Steering
Group 10—Air Intake System	Group 22—Late Model Power Steering
Group 15—Diesel Fuel System	Group 25—Power Brakes
Group 20—Speed Control Linkage	Group 30—Selective Control Valve, Breakaway Couplers, and Remote Cylinders
Group 25—Specifications and Special Tools	Group 35—Specifications and Special Tools
	<b>SECTION 80—MISCELLANEOUS</b>
<b>SECTION 40—ELECTRICAL SYSTEM</b>	Group 5—Front Axles
Group 5—Information and Wiring Diagrams	Group 10—Air Conditioning System
Group 10—Delcotron Charging Circuit	Group 15—Heating System
Group 15—Delco-Remy Starting Circuit	Group 20—Specifications and Special Tools
Group 20—John Deere Starting Circuit	
Group 25—Lighting and Accessory Circuits	
Group 30—Specifications and Special Tools	

*All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

Copyright© 1972  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved

## INTRODUCTION



*Use FOS Manuals for Reference*

This technical manual is part of a twin concept of service:

- *FOS Manuals—for reference*
- *Technical Manuals—for actual service*

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

*Fundamentals of Service (FOS) Manuals* cover *basic* theory of operation, *fundamentals* of trouble shooting, *general* maintenance, and *basic* types of failures and their causes. FOS Manuals are for training new men and for reference by experienced men.

*Technical Manuals* are *concise* service guides for a *specific* machine. Technical Manuals are on-the-job guides containing only the vital information needed by a journeyman mechanic.



When a serviceman should refer to a FOS Manual for more information, a FOS symbol like the one at the left is used in the TM to identify the reference.



*Use Technical Manuals for Actual Service*

Some features of this technical manual:

- *Table of contents at front of manual*
- *Exploded views showing parts relationship*
- *Photos showing service techniques*
- *Specifications grouped for easy reference*

This technical manual was planned and written for you—a journeyman mechanic. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.



This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.





Thank you very much  
for your reading.  
Please click here  
to get more information.