


John Deere 450C Crawler



TECHNICAL MANUAL

PDF



DOWNLOAD



TM1102
LITHO IN U.S.A.

JD450-C CRAWLER

Technical Manual
TM-1102 (May-87)

CONTENTS

Section 10 - GENERAL	Group 41	9550 Backhoe Control Valve
Group 5 Specifications	Group 42	9300 Backhoe Control Valve
Group 10 Predelivery, Delivery, and After-Sale Services	Group 45	Winch Control Valve
Group 15 Lubrication	Group 50	Miscellaneous Cylinders
Section 20 - ENGINE	Group 51	9250 Backhoe Cylinders
Group 5 Engine Removal and Installation	Group 52	9550 Backhoe Cylinders
Group 10 Basic Engine	Group 53	9300 Backhoe Cylinders
Group 15 Engine Lubrication System	Group 55	Miscellaneous Hydraulic Components
Group 20 Engine Cooling System	Group 60	Specifications and Special Tools
Group 25 Fuel System	Section 60 - MISCELLANEOUS COMPONENTS	
Group 30 Speed Control Linkage	Group 5 Tracks	
Group 35 Air Intake System	Loader (-216302)	
Group 40 Specifications and Special Tools	Dozer (-216337)	
Section 30 - ELECTRICAL SYSTEM	Group 6 Tracks	
Group 5 Batteries	Loader (216303-)	
Group 10 Charging System	Dozer (216338-)	
Group 15 Starting System	Group 10 Track Frame Assembly	
Group 20 Gauges and Switches	Group 15 Winch System	
Group 25 Specifications and Special Tools	Group 20 Winch Fairlead Assembly	
Section 40 - POWER TRAIN	Group 25 Loader Frame, Boom and Bucket	
Group 5 Engine Clutch Assembly	Group 30 Dozer Frames and Blades	
Group 10 H-L-R Transmission	Group 35 Lumber Fork and Pulpwood Loader	
Group 15 Steering Clutch and Brake Assembly	Group 40 9250 Backhoe Frame, Boom and Bucket	
Group 20 Final Drive Assembly	Group 41 9300 Backhoe Frame, Boom and Bucket	
Group 25 Power Take-Off and Winch Drive	Group 42 9550 Backhoe Frame, Boom and Bucket	
Group 30 Specifications and Special Tools	Group 45 Specifications and Special Tools	
Section 50 - HYDRAULIC SYSTEM	Section 70 - SYSTEM TESTING	
Group 5 Transmission Pump	Group 5 General Information	
Group 10 Main Hydraulic Pump	Group 10 Engine	
Group 15 Winch Hydraulic Pump	Group 15 Electrical System	
Group 20 Clutch Control Valve	Group 20 Power Train	
Group 25 Steering Valve	Group 25 Hydraulic System	
Group 30 Loader Control Valve	Group 26 Hydraulic System (Analyzer)	
Group 35 Bulldozer Control Valve	Group 30 Miscellaneous Components	
Group 40 9250 Backhoe Control Valve	Group 35 Specifications and Special Tools	


The specifications and design information contained in this manual were correct at the time it was printed. It is John Deere's policy to continually improve and update our machines. Therefore, the specifications and design information are subject to change without notice.

INDEX

Copyright® 1987
DEERE & COMPANY
Moline, Illinois
All rights reserved
Previous Editions

Copyright® 1986 DEERE & COMPANY
Copyright® 1980 DEERE & COMPANY
Copyright® 1979 DEERE & COMPANY
Copyright® 1976 DEERE & COMPANY
Copyright® 1974 DEERE & COMPANY
Copyright® 1973 DEERE & COMPANY

INTRODUCTION



Use FOS Manuals for Reference

This technical manual is part of a twin concept of service:

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

•FOS Manuals—for reference

Fundamentals of Service (FOS) Manuals cover basic theory of operation, *fundamentals* of trouble shooting, *general* maintenance, and *basic* types of failure and their causes. FOS Manuals are for training new personnel and for reference by experienced personnel.



When a service technician should refer to a FOS Manual for more information, a FOS symbol like the one at the left is used in the TM to identify the reference.

•Technical Manuals—for actual service

Technical Manuals are concise service guides for a specific machine. Technical manuals are on-the-job guides containing only the vital information needed by an experienced mechanic.



Use Technical Manuals for Actual Service

This technical manual was planned and written for you—an experienced mechanic. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.


Some features of this manual:

- Inside front cover - "Table of Contents" and "Maintenance Without Accident".
- Section 10 - General specifications and services.
- Sections 20 through 60 - Removal, repair, testing (components removed), installation, and adjustment.
- Section 70 - Detailed explanation of system operation, diagnosis, visual inspection, testing, and adjustments.
- Specifications grouped and illustrated at the end of each section.


MAINTENANCE WITHOUT ACCIDENT WORK SAFELY



T27999N

 This safety alert symbol identifies important safety messages in this manual and on the crawler. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

**EVERY EMPLOYER HAS A
SAFETY PROGRAM. KNOW
WHAT IT IS!**



T27501N

Consult your shop supervisor for specific instructions on a job, and the safety equipment required.


For instance, you may need: Hard hat, safety shoes, safety goggles, heavy gloves, reflector vests, ear protectors, respirators.

Litho in U.S.A.



T27502N


ALWAYS AVOID loose clothing or any accessory—flopping cuffs, dangling neckties and scarves, or rings and wrist watches—that can catch in moving parts and put you out of work.



T31961

BE ALERT!

Plan ahead — work safely — avoid accidental damage and injury. If a careless moment does cause an accident or fire, react quickly with the tools and skills at hand — know how to use a first aid kit and a fire extinguisher — and where to get assistance. In an emergency, split-second action is the key to safety.



T27504N



Thank you very much
for your reading.
Please click here
to get more information.