


John Deere JD310 Loader Backhoe



John Deere Dubuque works
TM-1036 (Feb-77)

LITHO IN U.S.A.

JD310 LOADER BACKHOE

Technical Manual TM-1036 (Feb-77)


CONTENTS

- Section 10 - GENERAL
 - Group 5 Specifications
 - Group 10 Predelivery, Delivery, and After-Sales Services
 - Group 15 Tune-up
 - Group 20 Lubrication
 - Group 25 Separation
 - Section 20 - ENGINE
 - Group 5 Diagnosis
 - Group 10 Basic Engine
 - Group 15 Lubrication System
 - Group 20 Governor and Speed Control Linkage
 - Group 25 Cooling System
 - Group 30 Specifications and Special Tools
 - Section 30 - FUEL SYSTEM
 - Group 5 Diagnosis
 - Group 10 Fuel Tank, Transfer Pump, and Filters
 - Group 15 Air Intake System
 - Group 20 Carburetor
 - Group 25 Fuel Injection Pump
 - Section 40 - ELECTRICAL SYSTEM
 - Group 5 Wiring Diagrams
 - Group 10 Charging System
 - Group 15 Starting Motor
 - Group 20 Ignition System
 - Group 25 Gauges and Switches
 - Section 50 - POWER TRAIN
 - Group 5 Diagnosis
 - Group 10 Clutch Assembly
 - Group 15 Transmission
 - Group 20 Reverser
 - Group 25 Differential
 - Group 30 Final Drive
 - Section 60 - STEERING AND BRAKES
 - Group 5 Hydraulic Brakes
 - Group 10 Power Steering
 - Section 70 - HYDRAULIC SYSTEM
 - Group 5 General Information, Testing, and Diagnosis
 - Group 6 System Testing (Analyzer)
 - Group 10 Hydraulic Pump
 - Group 15 Hydraulic Components
 - Group 20 Loader Control Valve
 - Group 25 Backhoe Control Valve (9405 and 9500)
 - Group 30 Hydraulic Cylinders
 - Group 35 9500 Backhoe Swing Cylinder
 - Section 80 - MISCELLANEOUS COMPONENTS
 - Group 5 Front Axle and Front Support
 - Group 10 Loader Frame, Boom and Bucket
 - Group 15 Backhoe Frame, Boom and Bucket
- INDEX

The specifications and design information contained in this manual were correct at the time it was printed. It is John Deere's policy to continually improve and update our machines. Therefore, the specifications and design information are subject to change without notice. Wherever applicable, specifications and design information are in accordance with SAE and IEMC standards.

Copyright © 1971
DEERE & COMPANY
Moline, Illinois
All rights reserved

INTRODUCTION



Use FOS Manuals for Reference

This technical manual is part of a twin concept of service:

- **FOS Manuals—**for reference
- **Technical Manuals—**for actual service


The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

Fundamentals of Service (FOS) Manuals cover basic theory of operation, *fundamentals* of trouble shooting, *general* maintenance, and *basic* types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced personnel.

Technical Manuals are *concise* service guides for a *specific* machine. Technical Manuals are on-the-job guides containing only the vital information needed by an experienced mechanic.



When a service technician should refer to a FOS Manual for more information, a FOS symbol like the one at the left is used in the TM to identify the reference.




Use Technical Manuals for Actual Service

Some features of this technical manual:

- *Table of contents at front of manual*
- *Exploded views showing parts relationship*
- *Photos showing service techniques*
- *Specifications grouped for easy reference*

This technical manual was planned and written for you—an experienced mechanic. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.

 This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

**COMPLETE PAGE LISTING
 WITH LATEST DATE LINES**

1,2	(Feb-77)	40-10-5,6	(Apr-73)
3,4	(May-77)	40-10-7,8	(Dec-71)
		40-15-1,2	(Feb-75)
10-5-1,2	(Aug-74)	40-15-3,4	(Aug-74)
10-5-3,4	(Jan-73)	40-15-5,6	(Aug-74)
10-10-1,2	(Dec-71)	40-20-1,2	(Jan-71)
10-10-3,4	(Jan-71)	40-20-3,4	(Jan-71)
10-15-1,2	(Jan-73)	40-25-1,2	(Feb-75)
10-15-3,4	(Jan-71)		
10-20-1,2	(Aug-74)	50-5-1,2	(May-77)
10-25-1,2	(Apr-73)	50-10-1,2	(Jul-73)
10-25-3,4	(May-77)	50-10-3,4	(Feb-75)
10-25-5,6	(Apr-73)	50-10-5,6	(May-77)
10-25-7,8	(Apr-73)	50-10-7,8	(May-77)
10-25-9,10	(Apr-73)	50-15-1,2	(Jan-73)
10-25-11,12	(Apr-73)	50-15-3,4	(Dec-71)
		50-15-5,6	(Jul-73)
20-5-1,2	(Dec-71)	50-15-7,8	(Jul-73)
20-10-1,2	(Jul-73)	50-15-9,10	(Jul-73)
20-10-3,4	(Oct-75)	50-15-11,12	(May-77)
20-10-5,6	(May-77)	50-20-1,2	(Jan-73)
20-10-7,8	(Feb-75)	50-20-3,4	(Jul-73)
20-10-9,10	(Feb-75)	50-20-5,6	(Jan-71)
20-10-11,12	(Dec-71)	50-20-7,8	(Jan-73)
20-10-13,14	(Dec-71)	50-20-9,10	(Jan-71)
20-15-1,2	(Jul-73)	50-20-11,12	(Apr-73)
20-15-3,4	(Feb-74)	50-20-13,14	(Oct-75)
20-20-1,2	(Jan-71)	50-20-15,16	(May-77)
20-20-3,4	(Dec-71)	50-20-17,18	(May-77)
20-20-5,6	(Feb-75)	50-25-1,2	(Feb-75)
20-25-1,2	(Apr-73)	50-25-3,4	(Feb-75)
20-25-3,4	(Apr-73)	50-25-5,6	(Feb-75)
20-30-1,2	(May-77)	50-30-1,2	(Jul-73)
20-30-3,4	(Oct-75)	50-30-3,4	(Jul-73)
20-30-5,6	(Apr-73)		
20-30-7,8	(Apr-73)	60-5-1,2	(Oct-75)
		60-5-3,4	(Dec-71)
30-5-1,2	(Dec-71)	60-5-5,6	(Feb-75)
30-10-1,2	(May-77)	60-5-7,8	(Oct-75)
30-10-3,4	(Dec-71)	60-5-9,10	(Feb-75)
30-15-1,2	(Dec-71)	60-5-11,12	(Feb-75)
30-20-1,2	(Oct-75)	60-10-1,2	(Oct-75)
30-20-3,4	(Jan-71)	60-10-3,4	(Aug-74)
30-20-5,6	(Jan-71)	60-10-5,6	(Feb-74)
30-25-1,2	(May-77)	60-10-7,8	(Aug-74)
30-25-3,4	(Jul-73)	60-10-9,10	(Aug-74)
		60-10-11,12	(Oct-75)
40-5-1,2	(Feb-74)	60-10-13,14	(Oct-75)
40-5-3,4	(Feb-75)	60-10-15,16	(Oct-75)
40-5-5,6	(Feb-75)	60-10-17,18	(Oct-75)
40-10-1,2	(Jan-71)		
40-10-3,4	(Jan-71)	70-5-1,2	(May-77)
		70-5-3,4	(May-77)

| Vertical lines indicate pages included with this revision.



Thank you very much
for your reading.
Please click here
to get more information.