
John Deere JD646 Compactor







JD646 COMPACTOR

TECHNICAL MANUAL TM-1073 (Mar-74)

CONTENTS


Section 10 -	GENERAL	Section 50 -	POWER TRAIN
Group 5	Specifications	Group 5	System Diagnosis
Group 10	Predelivery, Delivery, and After-	Group 10	Damper Assembly and Drive Shafts
	Sale Services	Group 15	Transmission Assembly
Group 15	Tune-Up and Adjustment	Group 20	Axle Assemblies
Group 20	Lubrication	Group 25	Differentials
Group 25	Compactor Separation	Group 30	Specifications and Special Tools
Group 30	Specifications and Special Tools		
		Section 60 -	POWER STEERING AND
Section 20 -	ENGINE		BRAKE SYSTEMS
Group 5	Diagnosis	Group 5	General Information, Testing, and
Group 10	Basic Engine		Diagnosis
Group 15	Engine Lubrication	Group 10	Hydraulic Pump
Group 20	Speed Control Linkage	Group 15	Filters, Oil Cooler, and Accumulators
Group 25	Engine Cooling	Group 20	Steering System
Group 30	Specifications and Special Tools	Group 25	Brake System
-		Group 30	Specifications and Special Tools
Section 30 -	FUEL SYSTEM		
Group 5	System Diagnosis	Section 70 -	HYDRAULIC SYSTEM (Loader Functions)
Group 10	Tank, Filters, and Transfer Pump	Group 5	General Information, Testing, and
Group 15	Air Intake System		Diagnosis
Group 20	Fuel Injection Pump	Group 10	Reservoir and Filters
Group 25	Robert Bosch Injection Nozzles	Group 15	Hydraulic Pump
Group 30	Specifications and Special Tools	Group 20	Control Valve
		Group 25	Return-to-Dig Valve
Section 40 -	ELECTRICAL SYSTEM	Group 30	Cylinders
Group 5	Wiring Diagrams	Group 35	Specifications and Special Tools
Group 10	Charging Circuit		
Group 15	Starting Circuit	Section 80 -	MISCELLANEOUS
Group 20	Gauges and Switches	Group 5	Frames
Group 25	Specifications and Special Tools	Group 10	Buckets
		Group 15	Multi-Purpose Bucket
		Group 20	Demolition Wheels
		Group 25	Specifications and Special Tools

INDEX

The specifications and design information contained in this manual were correct at the time it was printed. It is John Deere's policy to continually improve and update our machines. Therefore, the specifications and design information are subject to change without notice. Wherever applicable, specifications and design information are in accordance with SAE and IEMC standards.

Copyright 1972 DEERE & COMPANY Moline, Illinois All rights reserved

INTRODUCTION



Use FOS Manuals for Reference

This technical manual is part of a twin concept of service:

- FOS Manuals—for reference
- Technical Manuals—for actual service


The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of trouble shooting, general maintenance, and basic types of failures and their causes. FOS Manuals are for training new men and for reference by experienced men.

Technical Manuals are concise service guides for a specific machine. Technical Manuals are on-the-job guides containing only the vital information needed by a journeyman mechanic.



When a serviceman should refer to a FOS Manual for more information, a FOS symbol like the one at the left is used in the TM to identify the reference.



Use Technical Manuals for Actual Service

Some features of this technical manual:

- · Table of contents at front of manual
- · Exploded views showing parts relationship
- Photos showing service techniques
- · Specifications grouped for easy reference

This technical manual was planned and written for you—a journeyman mechanic. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.

This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

COMPLETE PAGE LISTING WITH LATEST DATE LINES

	1, 2	(Mar-74)	1	30-15-1, 2	(Jun-80)
1	3, 4	(Jun-80)		30-15-3, 4	(Oct-72)
	10 5 1 0	(Apr 75)		30-15-5, 6	(Oct-72)
	10-5-1, 2 10-5-3, 4	(Apr-75) (Apr-75)		30-20-1, 2	(May 72)
	10-3-3, 4	(Api-73)		30-20-1, 2	(May-73) (Oct-72)
	10-10-1, 2	(Oct-72)		00-20-0, 4	(001-72)
	10-10-3, 4	(Oct-72)		30-25-1, 2	(Oct-72)
	10-10-5, 6	(Apr-75)		,	,
				30-30-1, 2	(Oct-72)
	10-15-1, 2	(Oct-72)	ļ	30-30-3, 4	(Jun-80)
	10-15-3, 4	(Oct-72)			
	10.00.1.0	(4. 75)		40-5-1, 2	(Mar-74)
	10-20-1, 2	(Apr-75)		40-5-3, 4	(Oct-72)
	10.05.1.0	(Opt 70)		40-5-5, 6	(Oct-72)
	10-25-1, 2 10-25-3, 4	(Oct-72) (Apr-75)		40-5-7, 8	(Mar-74)
	10-25-5, 6	(Nov-73)		40-10-1, 2	(Nov-73)
	10 20 0, 0	(1101 70)		40-10-3, 4	(Oct-72)
	10-30-1, 2	(Nov-73)		40-10-5, 6	(Aug-73)
	,	,		40-10-7, 8	(Aug-73)
	20-5-1, 2	(Oct-72)		40-10-9, 10	(Aug-73)
	20-5-3, 4	(Oct-72)			
				40-15-1,2	(May-74)
	20-10-1, 2	(May-73)		40-15-3, 4	(May-73)
	20-10-3, 4	(Nov-73)		40-15-5, 6	(Aug-73)
	20-10-5, 6	(Apr-75)		40-15-7, 8	(Aug-73)
	20-10-7, 8 20-10-9, 10	(Nov-73) (May-73)		40-15-9, 10 40-15-11, 12	(Aug-73) (Mar-74)
	20-10-9, 10	(Apr-75)		40-15-13, 14	(May-74)
1	20-10-13, 14	(Jun-80)		40 10 10, 14	(Way 14)
•	20-10-15, 16	(Oct-72)		40-20-1, 2	(Oct-72)
	,				,
	20-15-1, 2	(Oct-72)		40-25-1, 2	(Aug-73)
	20-15-3, 4	(Oct-72)	1	40-25-3, 4	(Jun-80)
				40-25-5, 6	(Oct-72)
ı	20-20-1, 2	(Jun-80)		50 5 4 0	(O + 70)
	00.05.4.0	(4 75)		50-5-1, 2	(Oct-72)
	20-25-1, 2 20-25-3, 4	(Apr-75) (Apr-75)		50-10-1, 2	(Oct-72)
	20-25-5, 4	(Api-73)		50-10-3, 4	(Oct-72)
	20-30-1, 2	(Aug-73)		50-10-5, 6	(Oct-72)
	20-30-3, 4	(Apr-75)		30 10 0, 0	(001.2)
	20-30-5, 6	(May-73)		50-15-1, 2	(May-73)
1	20-30-7, 8	(Jun-80)		50-15-3, 4	(Oct-72)
				50-15-5, 6	(Oc-72)
	30-5-1, 2	(Oct-72)		50-15-7, 8	(Oct-72)
		(0.) -0)		50-15-9, 10	(May-73)
	30-10-1, 2	(Oct-72)		50-15-11, 12	(Apr-75)
	30-10-3, 4	(Oct-72)		50-15-13, 14	(Mar-74)
				50-15-15, 16	(Mar-74)

Vertical lines indicate pages included in this revision.



Thank you very much for your reading.

Please click here to get more information.