

317 Hydrostatic Tractor



TECHNICAL MANUAL

317 Hydrostatic Tractor

TM1208 (01OCT81) English



John Deere Lawn & Grounds Care Division TM1208 (01OCT81)

LITHO IN U.S.A. ENGLISH



INTRODUCTION

This technical manual contains service and maintenance information for the John Deere 317 Hydrostatic Tractor.

The manual is divided into sections. Each section pertains to a certain component or operational system of the tractor. The information is divided into groups within each section.

All sections of this technical manual should be carefully studied by the service technician. Much basic information such as the principles of 4-cycle engine operation, carburetion and ignition have been omitted. Such information can be found in any good library and is recommended reading for the new service technician before consulting this manual for service procedures.

Emphasis is placed on diagnosing malfunctions, analysis and testing. Diagnosing malfunctions lists possible troubles, their causes and how to correct them. Under specific components these troubles are analyzed to help the service technician understand what is causing the problem so it can be corrected rather than just replace parts and have the same problem keep recurring.

Specifications are found at the end of each Section for easy reference.



This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

Metric equivalents have been included, where applicable, throughout this technical manual.

Vertical lines appear in the margins of many of the pages. These lines identify new material and revised information that affects specifications, procedures, and other important instructions.

JOHN DEERE 317 HYDROSTATIC TRACTOR

Technical Manual TM-1208 (Oct-81)

TABLE OF CONTENTS

SECTION 10 - GENERAL Group 5 - Tractor Identification Group 7 - Tractor and Engine Change Identification Group 10 - Specifications Group 15 - Fuel and Lubricants Group 20 - Tune-up and Adjustments	SECTION 40 - ELECTRICAL SYSTEM Group 5 - General Information Group 10 - Cranking System Group 15 - Ignition System Group 20 - Charging System Group 25 - Lights Group 30 - PTO Clutch		
SECTION 20 - ENGINE - SER. NO. (-11,025,872) Group 5 - General Information Group 10 - Cylinder Heads, Valves and Breather Group 15 - Engine Removal and Installation Group 20 - Internal Components Group 25 - Specifications	SECTION 50 - POWER TRAIN Group 5 - General Information Group 10 - Brakes Group 15 - Hydrostatic Transmission Group 20 - Hydrostatic Control Linkage Group 25 - Differential and Axle SECTION 60 - HYDRAULIC SYSTEM		
SECTION 22 - ENGINE - SER. NO. (11,025,873-) Group 5 - General Information Group 10 - Cylinder Heads, Valves and Breather Group 15 - Engine Removal and Installation Group 20 - Internal Components Group 25 - Specifications	Group 5 - General Information Group 10 - Hydraulic Circuit Group 15 - Hydraulic Control Valve Group 17 - Flow Diverter Valve Group 20 - Hydraulic Cylinder SECTION 70 - MISCELLANEOUS		
SECTION 30 - FUEL SYSTEM Group 5 - General Information Group 10 - Carburetor - Engine Serial No. (-11,053,429) Group 12 - Carburetor - Engine Serial No. (11,053,430-)	Group 5 - Steering Linkage Group 10 - Front Wheels and Axles SECTION 80 - SPECIAL SERVICE TOOLS Group 5 - Engine Essential Service Tools Group 10 - Engine Convenience Service Tools Group 15 - Tractor Convenience Service Tools		
Group 15 - Governor Group 20 - Fuel Tank Group 25 - Fuel Pump Group 30 - Air Cleaner - Engine Serial No. (-11,025,872) Group 32 - Air Cleaner - Engine Serial No. (11,025,873-11,053,429)	SECTION 90 - TRACTOR ATTACHMENTS Group 5 - 49 Snow Thrower Group 10 - 41 and 48 Rotary Mowers Group 15 - 33 Rotary Tiller Group 20 - 542 PTO Attachment		
Group 34 - Air Cleaner - Engine Serial No. (11,053,430-) Group 35 - Specifications			

Copyright ® 1981 Deere & Company **Previous Editions** Copyright ® 1980 Deere & Company Copyright ® 1978 Deere & Company

notice).

(All information, illustrations and specifications con-

tained in this technical manual are based on the latest

information available at the time of publication. The

right is reserved to make changes at any time without



Thank you very much for your reading.

Please click here to get more information.