Compact Utility Tractor 2520 Series Repair, Test and Adjustments



# **TECHNICAL MANUAL**

**Compact Utility models 2520** 

TM2288 30 MAY 11 (ENGLISH)





TM2288-TECHNICAL MANUAL (g) by Belgreen v2.5

## **Table of contents**

#### **FOREWORD**

#### Section 10 - SAFETY

Group 05 - Safety

## Section 20 - SPECIFICATIONS AND INFORMATION

- Group 05 General Specifications
- Group 10 Fuel and Lubricants
- Group 15 Serial Number Locations

#### Section 30 - ENGINE

- Group 05 Specifications
- Group 10 Theory of Operation
- Group 15 Component Location
- Group 20 Diagnostics
- Group 25 Tests and Adjustments
- Group 30 Repair

## Section 40 - ELECTRICAL

- Group 05 General Information
- Group 10 Specifications
- Group 15 Component Location
- Group 20 System Schematics
- Group 25 Operation and Diagnostics
- Group 30 Tests and Adjustments

### Section 45 - EXPORT ELECTRICAL

- Group 05 Specifications
- Group 10 Component Location
- Group 15 Schematics & Harnesses
- Group 20 Operation & Diagnostics

## Section 50 - POWER TRAIN - HYDROSTATIC

- Group 05 Specifications
- Group 10 Component Location
- Group 15 Diagnostics
- Group 20 Theory of Operation
- Group 25 Tests and Adjustments
- Group 30 Repair

## Section 60 - HYDRAULICS

- Group 05 Specifications
- Group 10 Component Locations
- Group 15 Schematics
- Group 20 Operation and Diagnostics
- Group 25 Troubleshooting
- Group 30 Theory of Operation
- Group 35 Tests and Adjustments
- Group 40 Repair

### Section 70 - STEERING

- Group 05 Specifications
- Group 10 Component Location
- Group 15 Theory of Operation
- Group 20 Diagnostics
- Group 25 Tests and Adjustments
- Group 30 Repair

# Section 80 - BRAKES

- Group 05 Specifications
- Group 10 Component Location

TM2288-TECHNICAL MANUAL (g) by Belgreen v2.5

Group 15 - Theory of Operation

Group 20 - Diagnostics

Group 25 - Tests and Adjustments

Group 30 - Repair

# Section 90 - MISCELLANEOUS

Group 05 - Specifications

Group 10 - Repair

<- Go to Global Table of contents</p>
TM2288-TECHNICAL MANUAL

<- Go to Global Table of contents</p>
TM2288-TECHNICAL MANUAL

SAFETY (g) by Belgreen v2.0

## **Foreword**

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.



Thank you very much for your reading.

Please click here to get more information.