


# John Deere 400G Crawler Bulldozer Repair





# 400G CRAWLER BULLDOZER TECHNICAL MANUAL TM1412 (Mar-88) REPAIR

## SECTION AND GROUP CONTENTS

*NOTE: This manual covers machine repair. For Operation and Test information, see TM-1411.*

### SECTION I—GENERAL INFORMATION

- Group I—Introduction and Safety Information
- Group II—General Specifications
- Group III—Torque Values
- Group IV—Fuels and Lubrication
- Group V—Inspection Procedures

### SECTION 01—TRACKS

- Group 0130—Track Systems
  - Track Chain, Track Frame, Carrier Roller, Front Idler, Track Roller and Track Adjuster

### SECTION 02—AXLES AND SUSPENSION SYSTEMS

- Group 0250—Axle Shaft, Bearings, and Reduction Gears
  - Final Drive, Steering Brakes, Steering Clutch, Linkage, and Adjustments

### SECTION 03—TRANSMISSION

- Group 0315—Controls
- Group 0350—Gears, Shafts, Bearings and Power Shift Clutches
  - Transmission, Clutch Oil Pump, H-L-R Clutches, Valves, Oil Filter, Winch Drive, Drive Shaft, Ring Gear, Linkages and Adjustments
- Group 0360—Hydraulic System
  - Transmission Oil Filter and Transmission Oil Cooler

### SECTION 04—ENGINE

- Group 0400—Removal and Installation
  - Engine, Oil Pan, Fuel Injection Pump, Injection Nozzles, Thermostats, Fuel Transfer Pump and Water Pump

### SECTION 05—ENGINE AUXILIARY SYSTEMS

- Group 0505—Cold Weather Starting Aid
  - Starting Aid Solenoid and Nozzles
- Group 0510—Cooling System
  - Fan Belt, Blower Fan, Radiator, Oil Cooler, Pump and Radiator Support
- Group 0515—Speed Controls
- Group 0560—External Fuel Supply Systems
  - Fuel Tank

### SECTION 07—CLUTCH

- Group 0715—Controls
  - Clutch Pedal Linkage and Adjustment
- Group 0752—Elements
  - Engine Clutch Assembly and Clutch Housing

*Continued on next page*

*All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

COPYRIGHT © 1988  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved  
A JOHN DEERE ILLUSTRATION

**SECTION 09—STEERING SYSTEM**

Group 0960—Hydraulic System  
Steering Valve Spools

**SECTION 15—EQUIPMENT ATTACHING**

Group 1511—Fairlead

**SECTION 16—ELECTRICAL SYSTEM**

Group 1671—Batteries, Support, and Cables  
Group 1672—Alternator, Regulator, and Charging  
System Wiring  
Group 1673—Lighting System  
Group 1674—Wiring Harness and Switches  
Group 1676—Instruments and Indicators  
Logic Module, Relay, Circuit Break-  
ers, and Switches  
Group 1677—Motors and Actuators  
Starting Motor

**SECTION 17—FRAME, CHASSIS, OR  
SUPPORTING  
STRUCTURE**

Group 1740—Frames  
Side Frames

**SECTION 18—OPERATOR'S STATION**

Group 1810—Operator Enclosure  
Roll-Over Protective Structure  
(ROPS)  
Group 1821—Seat and Seat Belt

**SECTION 19—SHEET METAL AND  
STYLING**

Group 1910—Hood or Engine Enclosure  
Grille Housing and Cowl

**SECTION 30—WINCH**

Group 3015—Controls Linkage  
Group 3050—Winch Drive and Clutches  
Group 3060—Winch Hydraulic System

**SECTION 32—BULLDOZER**

Group 3201—Blade  
Group 3215—Control Linkage  
Group 3240—Frames  
Group 3260—Hydraulic System  
Hydraulic Oil Filter, Reservoir, Hy-  
draulic Pump, Pump Drive, Dozer  
Valve, Relief Valves and Cylinders

**SECTION 40—PTO OR WINCH DRIVE**

Group 4051—Gears, Shafts and Bearings  
Powershaft and Winch Drive

**SECTION 42—GROUND CONDITIONING  
TOOLS**

Group 4201—Teeth and Shanks  
Group 4240—Frame  
Group 4260—Hydraulic System  
Ripper Cylinder

**SECTION 99—DEALER FABRICATED  
TOOLS**

## INTRODUCTION

This manual is part of a total service support program.

### FOS Manuals—reference


### Technical Manuals—machine service

### Component Manuals—component service

*Fundamentals of Service (FOS) Manuals* cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

*Technical Manuals* are concise service guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed by an experienced service technician.

*Component Technical Manuals* are concise service guides for specific components. Component technical manuals are written as stand alone manuals covering multiple machine applications.



AB6;RW5559 053;INTRO2 030785

## FEATURES OF THIS TECHNICAL MANUAL

John Deere ILLUSTRATION format emphasizing illustrations and concise instructions in easy-to-use modules.

Emphasis on diagnosis, analysis, and testing so you can understand the problem and correct it.


Diagnostic information presented with the most logical and easiest to isolate problems first to help you identify the majority of routine failures quickly.

Step-by-step instructions for teardown and assembly.

Summary listing at the beginning of each group of all applicable specifications, wear tolerances, torque values, essential tools, and materials needed to do the job.

An emphasis throughout on safety—so you do the job right without getting hurt.

This technical manual was planned and written for you—an experienced service technician. Keep it in a permanent binder in the shop where it is handy. Refer to it when you need to know correct service procedures or specifications.



AB6;RW5560 053;INTRO3 071085



Thank you very much  
for your reading.  
Please click here  
to get more information.